

- power cable connector to the light is good connecting. The earth cable is yellow color.
- Please use banister brush, cotton swab, dust catcher or air sprayer to clean the surface or internal of the light.

o Main Features

- Master-slave control and multi-lights running control
- Standard DMX512 controller control, DMX address can be adjusted
- IP address code extended function
- Sound controlling mode, auto running mode and external control mode
- 65536 brightness levels which is the real 16 bits dimming and solve the low brightness shaking problem of 8 bits dimming. It make better uniform and soft lighting.
- It adopts TFT LCD touch display which brings easy and convenient control
- English or Chinese bilingual languages menu selections
- Electronic strobe 1~25/sec with soft light function

o DMX Channel Function

Channel Mode	Function	Function Details
13 Channels	18 Channels	
CH1	CH1	RGBW Dimming 0~255 Linear
CH2	CH2	RED 0~255 Linear
CH3	CH3	GREEN 0~255 Linear
CH4	CH4	BLUE 0~255 Linear
CH5	CH5	WHITE 0~255 Linear
CH6	CH6	ULTRAVIOLET 0~255 Linear
CH7	CH7	AMBER 0~255 Linear
CH8	CH8	User-defined Dimming It is used with display menu for testing.
CH9	CH9	Pan Scanning 0~540°
CH10	CH10	Tilt Scanning 0~270°
CH11	Pan Scanning Fine	16Bit
CH12	Tilt Scanning Fine	16Bit
CH11	CH13	Scanning Speed Fast to Slow
CH12	CH14	Zooming 0~255 Linear

o Menu Instruction



This interface is the display menu. Touch it to enter submenu to make setting. The submenu includes Address, RunMode, TestMode, Language, SetUp and SysInfo. Below are the details of submenu. After setting, please press ENTER to saving setting.

- ❖ Address
 - 001
 - 512
- ❖ RunMode
 - DMX
 - Auto
 - Sound
 - Return
- ❖ Testmode