

15CHS

CHS	FUNCTIONS	INTRODUCTIONS
1	X	0-255 X
2	X FINE	0-255 16X FINE
3	Y	0-255 Y
4	Y FINE	0-255 16 Y FINE
5	XY Speed	0-255 XY speed
6	Dimming	0-255 Dimming
7	Strobe	0-255 Strobe
8	Color Wheel	0-9 Color 1, 10-19 Color 2, 20-29 Color 3, 30-39 Color 4, 40-49 Color 5, 50-59 Color 6, 60-69 Color 7, 70-79 Color 8, 80-89 Color 9, 90-99 Color 10, 100-109 Color 11, 110-119 Color 12, 120-129 Color 13, 130-139 Color 14, 140-149 Color 15, 150-152 Color 16, 153-255 Flow Effect
9	Focus	0-255 Focus
10	GOBO	0-9 Gobo 1, 10-19 Gobo 2, 20-29 Gobo 3, 30-39 Gobo 4, 40-49 Gobo 5, 50-59 Gobo 6, 60-69 Gobo 7, 70-79 Gobo 8. 80-99 Gobo 1 Shake, 100-119 Gobo 2 Shake, 120-139 Gobo 3 Shake, 140-159 Gobo 4 Shake, 160-179 Gobo 5 Shake, 180-199 Gobo 6 Shake, 200-219 Gobo 7 Shake, 220-255 Flow Effect
11	Rotated Gobo Turning	61-158 Forward, 159-255 reversal.
12	Fixed Gobo	0-10 Gobo 1, 11-21 Gobo 2, 22-32 Gobo 3, 33-43 Gobo 4, 44-54 Gobo 5, 55-65 Gobo 6, 66-76 Gobo 7, 77-87 Gobo 8, 88-98 Gobo 9, 99-107 Gobo 1, 108-122 Gobo 1 Shake,

		123-137 Gobo 2 Shake, 138-152 Gobo 3 Shake, 153-167 Gobo 4 Shake, 168-182 Gobo 5 Shake, 183-197 Gobo 6 Shake, 198-212 Gobo 7 Shake, 213-227 Gobo 8 Shake, 228-255 Flow Effect
13	Prism	0-19 NO, 20-255, Prism Rotating slow to fast.
14	AUTO Model	AUTO Model
15	REST	252-255, 3s REST





