

## DMX CONTROL

## 5 CANALI

| MODE<br>5 Ch | FUNCTION                                                                                                                                                                                              | DMX<br>Value                                        |
|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------|
| 1            | <b>RED</b><br>0~100%                                                                                                                                                                                  | 000 - 255                                           |
| 2            | <b>GREEN</b><br>0~100%                                                                                                                                                                                | 000 - 255                                           |
| 3            | <b>BLUE</b><br>0~100%                                                                                                                                                                                 | 000 - 255                                           |
| 4            | <b>WHITE</b><br>0~100%                                                                                                                                                                                | 000 - 255                                           |
| 5            | <b>DIMMER SPEED MODE</b><br>Preset dimmer speed from display menu<br>Dimmer speed mode off<br>Dimmer speed mode1 (fast speed)<br>Dimmer speed mode2 (middle speed)<br>Dimmer speed mode3 (slow speed) | 000-051<br>052-101<br>102-152<br>153-203<br>204-255 |

## 7 CANALI

| MODE<br>7 Ch | FUNCTION                                                                                                                                                                                              | DMX<br>Value                                        |
|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------|
| 1            | <b>DIMMER</b><br>0~100%                                                                                                                                                                               | 000 - 255                                           |
| 2            | <b>RED</b><br>0~100%                                                                                                                                                                                  | 000 - 255                                           |
| 3            | <b>GREEN</b><br>0~100%                                                                                                                                                                                | 000 - 255                                           |
| 4            | <b>BLUE</b><br>0~100%                                                                                                                                                                                 | 000 - 255                                           |
| 5            | <b>WHITE</b><br>0~100%                                                                                                                                                                                | 000 - 255                                           |
| 6            | <b>STROBE</b><br>No function<br>Strobe Slow to Fast                                                                                                                                                   | 000 - 010<br>011 - 255                              |
| 7            | <b>DIMMER SPEED MODE</b><br>Preset dimmer speed from display menu<br>Dimmer speed mode off<br>Dimmer speed mode1 (fast speed)<br>Dimmer speed mode2 (middle speed)<br>Dimmer speed mode3 (slow speed) | 000-051<br>052-101<br>102-152<br>153-203<br>204-255 |

## 10 CANALI

| MODE<br>10 Ch | FUNCTION                                                                                                                                                                                                                                                                                                                                                                                                                           | DMX<br>Value                                                                                                                                                                                                                                                                  |
|---------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1             | <b>DIMMER</b><br>0~100%                                                                                                                                                                                                                                                                                                                                                                                                            | 000 - 255                                                                                                                                                                                                                                                                     |
| 2             | <b>RED</b><br>0~100%                                                                                                                                                                                                                                                                                                                                                                                                               | 000 - 255                                                                                                                                                                                                                                                                     |
| 3             | <b>GREEN</b><br>0~100%                                                                                                                                                                                                                                                                                                                                                                                                             | 000 - 255                                                                                                                                                                                                                                                                     |
| 4             | <b>BLUE</b><br>0~100%                                                                                                                                                                                                                                                                                                                                                                                                              | 000 - 255                                                                                                                                                                                                                                                                     |
| 5             | <b>WHITE</b><br>0~100%                                                                                                                                                                                                                                                                                                                                                                                                             | 000 - 255                                                                                                                                                                                                                                                                     |
| 6             | <b>STROBE</b><br>No function<br>Strobe Slow to Fast                                                                                                                                                                                                                                                                                                                                                                                | 000 - 010<br>011 - 255                                                                                                                                                                                                                                                        |
| 7             | <b>COLOR MACRO</b><br>No Function<br>R 100%, G 0~100%, B 0 %<br>R 100%~0 %, G 100%, B 0 %<br>R 0 %, G 100%, B 0~100%<br>R 0 %, G 100~0 %, B 100%<br>R 0~100%, G 0 %, B 100%<br>R 100%, G 0 %, B 100~0 %<br>R 100%, G 0~100%, B 0~100%<br>R 100~0 %, G 100~0 %, B 100%<br>R 100%, G 100%, B 100%, W 100%<br>Color 1<br>Color 2<br>Color 3<br>Color 4<br>Color 5<br>Color 6<br>Color 7<br>Color 8<br>Color 9<br>Color 10<br>Color 11 | 000 - 010<br>011 - 030<br>031 - 050<br>051 - 070<br>071 - 090<br>091 - 110<br>111 - 130<br>131 - 150<br>151 - 170<br>171 - 200<br>201 - 205<br>206 - 210<br>211 - 215<br>216 - 220<br>221 - 225<br>226 - 230<br>231 - 235<br>236 - 240<br>241 - 245<br>246 - 250<br>251 - 255 |

# ARCP0D48Q

## 10 CANALI

| MODE<br>10 Ch                    | FUNCTION                              | DMX<br>Value |
|----------------------------------|---------------------------------------|--------------|
| 8                                | <b>EFFECTS</b>                        |              |
|                                  | NO Function                           | 000-010      |
|                                  | Effect 1                              | 011-037      |
|                                  | Effect 2                              | 038-064      |
|                                  | Effect 3                              | 065-091      |
|                                  | Effect4                               | 092-118      |
|                                  | Effect5 (Effects1- 4)                 | 119-145      |
|                                  | Effect 6                              | 146-172      |
|                                  | Effect 7                              | 173-199      |
| Effect 8                         | 200-226                               |              |
| Effect 9 (Effects6- 8)           | 227-255                               |              |
| 9                                | <b>EFFECTS SPEED</b>                  |              |
|                                  | Effects speed slow to fast            | 000 - 255    |
| 10                               | <b>DIMMER SPEED MODE</b>              |              |
|                                  | Preset dimmer speed from display menu | 000 - 051    |
|                                  | Dimmer speed mode off                 | 052 - 101    |
|                                  | Dimmer speed mode 1 (fast speed)      | 102 - 152    |
|                                  | Dimmer speed mode 2 (middle speed)    | 153 - 203    |
| Dimmer speed mode 3 (slow speed) | 204 - 255                             |              |

## 17 CANALI

| MODE<br>17 Ch                   | FUNCTION                              | DMX<br>Value |
|---------------------------------|---------------------------------------|--------------|
| 1                               | <b>RED 1</b><br>0~100%                | 000 - 255    |
| 2                               | <b>GREEN 1</b><br>0~100%              | 000 - 255    |
| 3                               | <b>BLUE 1</b><br>0~100%               | 000 - 255    |
| 4                               | <b>WHITE 1</b><br>0~100%              | 000 - 255    |
| 5                               | <b>RED 2</b><br>0~100%                | 000 - 255    |
| 6                               | <b>GREEN 2</b><br>0~100%              | 000 - 255    |
| 7                               | <b>BLUE 2</b><br>0~100%               | 000 - 255    |
| 8                               | <b>WHITE 2</b><br>0~100%              | 000 - 255    |
| 9                               | <b>RED 3</b><br>0~100%                | 000 - 255    |
| 10                              | <b>GREEN 3</b><br>0~100%              | 000 - 255    |
| 11                              | <b>BLUE 3</b><br>0~100%               | 000 - 255    |
| 12                              | <b>WHITE 3</b><br>0~100%              | 000 - 255    |
| 13                              | <b>RED 4</b><br>0~100%                | 000 - 255    |
| 14                              | <b>GREEN 4</b><br>0~100%              | 000 - 255    |
| 15                              | <b>BLUE 4</b><br>0~100%               | 000 - 255    |
| 16                              | <b>WHITE 4</b><br>0~100%              | 000 - 255    |
| 17                              | <b>DIMMER SPEED MODE</b>              |              |
|                                 | Preset dimmer speed from display menu | 000-051      |
|                                 | Dimmer speed mode off                 | 052-101      |
|                                 | Dimmer speed mode1 (fast speed)       | 102-152      |
|                                 | Dimmer speed mode2 (middle speed)     | 153-203      |
| Dimmer speed mode3 (slow speed) | 204-255                               |              |

# ARCPD48Q

## 22 CHANNEL

| MODE<br>22 Ch | FUNCTION                                              | DMX<br>Value           |
|---------------|-------------------------------------------------------|------------------------|
| 1             | <b>DIMMER</b><br>0~100%                               | 000 - 255              |
| 2             | <b>STROBE 1</b><br>No function<br>Strobe Slow to Fast | 000 - 010<br>011 - 255 |
| 3             | <b>STROBE 2</b><br>No function<br>Strobe Slow to Fast | 000 - 010<br>011 - 255 |
| 4             | <b>STROBE 3</b><br>No function<br>Strobe Slow to Fast | 000 - 010<br>011 - 255 |
| 5             | <b>STROBE 4</b><br>No function<br>Strobe Slow to Fast | 000 - 010<br>011 - 255 |
| 6             | <b>RED 1</b><br>0~100%                                | 000 - 255              |
| 7             | <b>GREEN 1</b><br>0~100%                              | 000 - 255              |
| 8             | <b>BLUE 1</b><br>0~100%                               | 000 - 255              |
| 9             | <b>WHITE 1</b><br>0~100%                              | 000 - 255              |
| 10            | <b>RED 2</b><br>0~100%                                | 000 - 255              |
| 11            | <b>GREEN 2</b><br>0~100%                              | 000 - 255              |
| 12            | <b>BLUE 2</b><br>0~100%                               | 000 - 255              |
| 13            | <b>WHITE 2</b><br>0~100%                              | 000 - 255              |
| 14            | <b>RED 3</b><br>0~100%                                | 000 - 255              |
| 15            | <b>GREEN 3</b><br>0~100%                              | 000 - 255              |
| 16            | <b>BLUE 3</b><br>0~100%                               | 000 - 255              |
| 17            | <b>WHITE 3</b><br>0~100%                              | 000 - 255              |

## 22 CHANNEL

| MODE<br>22 Ch | FUNCTION                                                                                                                                                                                              | DMX<br>Value                                        |
|---------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------|
| 18            | <b>RED 4</b><br>0~100%                                                                                                                                                                                | 000 - 255                                           |
| 19            | <b>GREEN 4</b><br>0~100%                                                                                                                                                                              | 000 - 255                                           |
| 20            | <b>BLUE 4</b><br>0~100%                                                                                                                                                                               | 000 - 255                                           |
| 21            | <b>WHITE 4</b><br>0~100%                                                                                                                                                                              | 000 - 255                                           |
| 22            | <b>DIMMER SPEED MODE</b><br>Preset dimmer speed from display menu<br>Dimmer speed mode off<br>Dimmer speed mode1 (fast speed)<br>Dimmer speed mode2 (middle speed)<br>Dimmer speed mode3 (slow speed) | 000-051<br>052-101<br>102-152<br>153-203<br>204-255 |