

MOSAICOXL

28CH	30CH	35CH	Record Scenes	Function	Value	Percent/Setting
1	1	1	1	Shutter	000-031 032-063 064-095 096-127 128-159 160-191 192-223 224-255	Shutter closed No function (shutter open) Shutter effect slow to fast No function (shutter open) Pulse-effect in sequences No function (shutter open) Random Shutter effect slow to fast No function (shutter open)
2	2	2	2	Dimmer	000-255	0~100%
-	-	3	-	Dimmer Fine	000-255	0~100%
3	3	4	3	Cyan	000-255	0~100%
4	4	5	4	Magenta	000-255	0~100%
5	5	6	5	Yellow	000-255	0~100%
6	6	7	6	CTO	000-255	0~100%
7	7	8	7	Color	000-004 005-009 010-013 014-018 019-022 023-027 028-031 032-036 037-040 041-045 046-049 050-054 055-058 059-063 064-095 096-127 128-255	Open Open+Color1 Color1 Color1+Color2 Color2 Color2+ Color3 Color3 Color3+ Color4 Color4 Color4+Color5 Color5 Color5+ Color6 Color6 Color6+ Open Stop to fast(Forward Spin) Fast to stop(Revers Spin) Positioning from 0-360 degrees(Indexing)
8	8	9	8	Gobo	000-005 006-010 011-015 016-020 021-025 026-030 031-035 036-040 041-055 056-070 071-085 086-100 101-115 116-130 131-145 146-200 201-255	Open Position 1 Position 2 Position 3 Position 4 Position 5 Position 6 Position 7 Position 1 (Position 1 Shake,from slow to fast) Position 2 (Position 2 Shake,from slow to fast) Position 3 (Position 3 Shake,from slow to fast) Position 4 (Position 4 Shake,from slow to fast) Position 5 (Position 5 Shake,from slow to fast) Position 6 (Position 6 Shake,from slow to fast) Position 7 (Position 7 Shake,from slow to fast) Stop to fastest (Forward Wheel Spin) Stop to fastest (Reverse Wheel Spin)
9	9	10	9	RGobo	000-191 192-221 222-225 226-255	Positioning from 0-360 degrees(Indexing) Slowest to fastest(Forward Spin) Stop Fastest to Slowest(Reverse Spin)
10	-	11	10	Prism Rot	000-000 001-127 128-189 190-193 194-255	Prism Off Index Fast to Slow Stop Slow to Fast
-	10	-	-	Prism	000-020 021-127 128-255	Prism Off Indexed Rotation
-	11	-	-	RPrism	000-255 000-127 128 129-255	Index Fast to Slow Stop Slow to Fast
11	12	12	11	Frost 1	000-255	Frost 0->100%
12	13	13	12	Frost 2	000-255	Frost 0->100%
13	14	14	13	Focus	000-255	0~100%
-	-	15	-	Focus Fine	000-255	0~100%
14	15	16	14	Zoom	000-255	0~100%
-	-	17	-	Zoom Fine	000-255	0~100%
15	/	-	-	Animation Wheel	000-003 004-127 128-131 132-255	Open/No Function Forward stop to fastest Stop Reverse stop to fastest
/	16	18	15	Animation	000-007 008-255	Effect Off Linear insertion
/	17	19	16	Animation Rotation	000-127 128- 189190- 193 194-	Stop Fastest to Slowest(Forward Spin) Stop Slowest to fastest(Reverse Spin)

MOSAICOXL

					255	
16	18	20	17	Iris	000-063 064-127 128-191 192-255	From large to small Open and close by arrive slow to fast (Effects) Open from slow to fast (Effects) Close from slow to fast (Effects)
17	19	21	18	Framing Shutter 1 movement	000-255	Movement from outward to inward
18	20	22	19	Framing Shutter 1 swivelling	000-127 128 129-255	Swivelling from -25 degrees towards 0 degrees 0 degrees Swivelling from 0 degrees to +25 degrees
19	21	23	20	Framing Shutter 2 movement	000-255	Movement from outward to inward
20	22	24	21	Framing Shutter 2 swivelling	000-127 128 129-255	Swivelling from -25 degrees towards 0 degrees 0 degrees Swivelling from 0 degrees to +25 degrees
21	23	25	22	Framing Shutter 3 movement	000-255	Movement from outward to inward
22	24	26	23	Framing Shutter 3 swivelling	000-127 128 129-255	Swivelling from -25 degrees towards 0 degrees 0 degrees Swivelling from 0 degrees to +25 degrees
23	25	27	24	Framing Shutter 4 movement	000-255	Movement from outward to inward
24	26	28	25	Framing Shutter 4 swivelling	000-127 128 129-255	Swivelling from -25 degrees towards 0 degrees 0 degrees Swivelling from 0 degrees to +25 degrees
25	27	29	26	Framing Shutters Rotation	000-127 128 129-255	Rotation from left to center Center Rotation from center to right
26	28	30	-	Shutters Macros	000-003 004-011 012-018 019-025 026-032 033-039 040-047 048-054 055-061 062-068 069-075 076-082 083-090 091-097 098-104 105-111 112-118 119-125 126-133 134-140 141-147 148-155 156-161 162-168 169-176 177-183 184-190 191-197 198-204 205-211 212-219 220-226 227-233 234-240 241-247 248-255	No Function Macro 1 Macro 2 Macro 3 Macro 4 Macro 5 Macro 6 Macro 7 Macro 8 Macro 9 Macro 10 Macro 11 Macro 12 Macro 13 Macro 14 Macro 15 Macro 16 Macro 17 Macro 18 Macro 19 Macro 20 Macro 21 Macro 22 Macro 23 Macro 24 Macro 25 Macro 26 Macro 27 Macro 28 Macro 29 Macro 30 Macro 31 Macro 32 Macro 33 Macro 34 Macro 35
27	29	31	-	Shutters Macro Speed	000-255	Speed From Slow to Fast
28	30	-	-	Control	000-059 060-069 070-079 080-089 090-099 100-119 110-119 120-129 130-139 140-149 150-159 160-169 170-179 180-199 200-209 210-255	No function Enable blackout while color change (Hold 3 Second) Disable blackout while color change (Hold 3 Second) Enable blackout while gobo change (Hold 3 Second) Disable blackout while gobo change (Hold 3 Second) Cyan/Magenta/Yellow/CTO/Color Reset (Hold 3 Second) Shutters Reset (Hold 3 Second) Gobo Reset (Hold 3 Second) Prism Reset (Hold 3 Second) Focus Reset (Hold 3 Second) Zoom Reset (Hold 3 Second) Frost Reset (Hold 3 Second) Effect Reset (Hold 3 Second) No function Reset all (Hold 3 Second) No function

MOSAICOXL

-	-	32	-	Show	000-063 064-127 128-191 192-255	No Function Show 1 Show 2 Show 3
-	-	33	-	Chase	000-028 029-056 057-085 086-113 114-141 142-170 171-198 199-226 227-255	No Function Chase 1 Chase 2 Chase 3 Chase 4 Chase 5 Chase 6 Chase 7 Chase 8
-	-	34	-	Scenes	000-007 008-015 016-023 024-030 031-038 039-046 047-054 055-061 062-069 070-077 078-085 086-092 093-100 101-108 109-115 116-123 124-131 132-139 140-146 147-154 155-162 163-170 171-177 178-185 186-193 194-200 201-208 209-216 217-224 225-231 232-239 240-247 248-255	No Function Scene 1 Scene 2 Scene 3 Scene 4 Scene 5 Scene 6 Scene 7 Scene 8 Scene 9 Scene 10 Scene 11 Scene 12 Scene 13 Scene 14 Scene 15 Scene 16 Scene 17 Scene 18 Scene 19 Scene 20 Scene 21 Scene 22 Scene 23 Scene 24 Scene 25 Scene 26 Scene 27 Scene 28 Scene 29 Scene 30 Scene 31 Scene 32
-	-	35	/	Record Scenes	000-010 011-128 129-255	No Function Edit Scene Mode Record Scene Mode (Hold 3S and Save)