




SMARTOWER

DMX CONTROL

SMARTOWER				
8CH	15CH	18CH	SMARTOWER FUNCTION	DMX Value
1	1	1	LED STRIP SHUTTER Shutter closed Strobe effect slow to fast No function (shutter open) Pulse-effect in sequences No function (shutter open) Random strobe effect slow to fast No function (shutter open)	000 - 010 011 - 082 083 - 093 094 - 163 164 - 174 175 - 244 245 - 255
2	2	2	LED STRIP DIMMER Dimmer 0% ~ 100%	000 - 255
	3	3	LED STRIP DIMMER FADE OUT 0% to 100%	000 - 255
3	4	4	LED STRIP VIRTUAL COLOR FUNCTION On Function White presets Function Forward Spin Reverse Spin Continuous Color Bounce TBD	000 - 015 016 - 031 032 - 047 048 - 063 064 - 079 080 - 111 112 - 255
4	5	5	LED STRIP VIRTUAL COLOR1 White presets Function White 2000K ~ 2700K White 2700K ~ 3200K White 3200K ~ 4200K White 4200K ~ 5600K White 5600K ~ 8000K White 8000K ~ 10000K Forward Spin Rainbow Effect (Slow->Fast) Reverse Spin Rainbow Effect (Slow->Fast) Continuous & Color Bounce Black Red Green Blue White Pastel red Pastel green Pastel blue Cyan Magenta Yellow Light Yellow Light Blue Light Magenta Full white Full white ~ 3200K White 3200K ~ 4200K White 4200K ~ 5600K	000 - 042 043 - 085 086 - 128 129 - 171 172 - 214 215 - 255 000 - 255 000 - 255 000 - 000 001 - 013 014 - 027 028 - 041 042 - 055 056 - 069 070 - 083 084 - 097 098 - 111 112 - 125 126 - 139 140 - 153 154 - 167 168 - 181 182 - 195 196 - 225 226 - 235 236 - 255

SMARTOWER

8CH	15CH	18CH	SMARTOWER FUNCTION	DMX Value
5	6	6	LED STRIP VIRTUAL COLOR2 (Only On Color Bounce) Black Red Green Blue White Pastel red Pastel green Pastel blue Cyan Magenta Yellow Light Yellow Light Blue Light Magenta Full white Full white ~ 3200K White 3200K ~ 4200K White 4200K ~ 5600K	000 - 000 001 - 013 014 - 027 028 - 041 042 - 055 056 - 069 070 - 083 084 - 097 098 - 111 112 - 125 126 - 139 140 - 153 154 - 167 168 - 181 182 - 195 196 - 225 216 - 235 236 - 255
6		7	LED STRIP RED  0~100%	000 - 255
7		8	LED STRIP GREEN  0~100%	000 - 255
8		9	LED STRIP BLUE  0~100%	000 - 255
	7	10	LED STRIP PATTERN On Pattern Pattern control Pattern Effect Random Pattern Effect	000 - 015 016 - 031 032 - 176 177 - 255
	8	11	LED STRIP PATTERN SPEED Pattern control Picture Effect 1-250 Pattern Effect & Random Pattern Effect Static indexing Forward Slow to fastest Stop Reverse Slow to fastest	003 - 252 000 - 023 024 - 137 138 - 141 142 - 255
	9	12	LED STRIP DIMMER TRANSITION Dimmer 0% ~ 100%	000 - 255
	10	13	LED STRIP FOREGROUND No Function Foreground Color	000 - 003 004 - 255
	11	14	LED STRIP FOREGROUND DIMMER Dimmer 0% ~ 100%	000 - 255
	12	15	LED STRIP FOREGROUND SHUTTER Shutter closed Strobe effect slow to fast No function (shutter open) Random strobe effect slow to fast No function (shutter open)	000 - 010 011 - 163 164 - 174 175 - 244 245 - 255

SMARTOWER

			SMARTOWER FUNCTION	DMX Value
8CH	15CH	18CH		
	13	16	LED STRIP BACKGROUND No Function Foreground Color	000 - 003 004 - 255
	14	17	LED STRIP BACKGROUND DIMMER Dimmer 0% ~ 100%	000 - 255
	15	18	LED STRIP BACKGROUND SHUTTER Shutter closed Strobe effect slow to fast No function (shutter open) Random strobe effect slow to fast No function (shutter open)	000 - 010 011 - 163 164 - 174 175 - 244 245 - 255