

DMX Charter for XP-900

Reduced Mode	Standard Mode	Value	Function
1	1	Dimmer	
		0-255	0-100%
2	2	Strobe	
		0-3	Close
		4-103	Strobe
		104-107	Open
		108-207	Pulse Strobe
		208-212	Open
		213-251	Random Strobe
		252-255	Open
3	3	Pan	
		0-255	0-100%
4	4	Fine Pan	
		0-255	0-100%
5	5	Tilt	
		0-255	0-100%
6	6	Fine Tilt	
		0-255	0-100%
7	7	Pan/Tilt Speed	
		0-255	Fast-Slow
8	8	Fade Scroll	
		0-3	No function
		4-255	Fade Scroll Slow to Fast
9	9	Chase Scroll	
		0-3	No function
		4-255	Chase Scroll Slow to Fast
10	10	CTO	
		0-22	No Function
		23-45	2800K
		46-68	3200K
		69-91	3600K
		92-114	4500K
		115-137	5000K
138-160	5600K		

		161-183	6200K
		184-206	6800K
		207-229	7500K
		230-255	8500K
11	11	Red Color Intensity	
		0-255	0-100%
12	12	Green Color Intensity	
		0-255	0-100%
13	13	Blue Color Intensity	
		0-255	0-100%
14	14	White Color Intensity	
		0-255	0-100%
15	15	Zoom	
		0-255	0-100%
16	16	Reset	
		0-99	No function
		100-149	Pan/Tilt Reset
		150-199	Zoom Reset
		200-255	All Reset
	17	Circle 1 LED	
		0-255	0-100% Red color Intensity
	18	Circle 1 LED	
		0-255	0-100% Green color Intensity
	19	Circle 1 LED	
		0-255	0-100% Blue color Intensity
	20	Circle 1 LED	
		0-255	0-100% White color Intensity
	21	Circle 2 LED	
		0-255	0-100% Red color Intensity
	22	Circle 2 LED	
		0-255	0-100% Green color Intensity
	23	Circle 2 LED	
		0-255	0-100% Blue color Intensity
24	Circle 2 LED		
	0-255	0-100% White color Intensity	
25	Circle 3 LED		
	0-255	0-100% Red color Intensity	

	26	Circle 3 LED	
		0-255	0-100% Green color Intensity
	27	Circle 3 LED	
0-255		0-100% Blue color Intensity	
	28	Circle 3 LED	
		0-255	0-100% White color Intensity