

ECLIPSEFS

DMX CONTROL

Channel													FUNCTION	DMX Value
Tun	3200K	5400K	6500K	1CH	2CH	3CH	RGB	4CH RGLB	5CH	5CH RGLB	8CH	13CH		
1	1	1	1	1	1	1			1	1	1	1	Dimmer Dimmer(Close to Open)	000 - 255
									2			2	Dimmer fine Dimmer fine 0->100%	000 - 255
						2			3				CTC CTC 2000K ->10000K	000 - 255
									4				CTC Fine CTC Fine	000 - 255
					2								CTC Preset Full 2000K->2700K 2700K->3200K 3200K->4200K 4200K->5600K 5600K->8000K 8000K->10000K	000 - 025 026 - 063 064 - 101 102 - 139 140 - 177 178 - 215 216 - 255
2							1	1		2	2	3	Red Red 0->100%	000 - 255
												4	Red fine Red fine 0->100%	000 - 255
3							2	2		3	3	5	Green Green 0->100%	000 - 255
												6	Green fine Green Fine 0->100%	000 - 255
4							3	3		4	4	7	Blue Blue 0->100%	000 - 255
												8	Blue fine Blue Fine 0->100%	000 - 255
5								4		5	5	9	Lime Lime 0->100%	000 - 255
												10	Lime fine Lime Fine 0->100%	000 - 255
											6	11	Virtual Color No Function Red Green Blue Lime Cyan Magenta Yellow Orange Light Yellow Light Blue Light Pink 2000K->2700K 2700K->3200K 3200K->4200K 4200K->5600K 5600K->8000K 8000K->10000K	000 - 003 004 - 005 006 - 007 008 - 009 010 - 011 012 - 013 014 - 015 016 - 017 018 - 019 020 - 021 022 - 023 024 - 025 026 - 063 064 - 101 102 - 139 140 - 177 178 - 215 216 - 255
											7	12	Shutter Function Normal Shutter Functions Strobe effect slow to fast	000 - 003 003 - 255
						3			5		8	13	Dimmer Fade 0->100%	000 - 255