

17 channel mode (COLOUR 16BIT):

Channel	Value	Function
CH1	000-255	Master dimmer (0-100%)
CH2	000-255	Dimmer fine (0-100%)
CH3	000-255	Red (0-100%)
CH4	000-255	Red fine (0-100%)
CH5	000-255	Green (0-100%)
CH6	000-255	Green fine (0-100%)
CH7	000-255	Blue (0-100%)
CH8	000-255	Blue fine (0-100%)
CH9	000-255	Amber (0-100%)
CH10	000-255	Amber fine (0-100%)
CH11	000-255	Lime (0-100%)
CH12	000-255	Lime fine (0-100%)
CH13	000-010	No function
	011-020	L106 - Primary Red
	021-030	R05 - Rose Tint
	031-040	L194 - Surprise Pink
	041-050	R54 - Special Lavender
	051-060	L019 - Fire
	061-070	R08 - Pale Gold
	071-080	R89 - Moss Green
	081-090	R86 - Pea Green
	091-100	L213 - White Flame Green
	101-110	R377 - Iris Purple
	111-120	R80 - Primary Blue
	121-130	L202 - Half C.T. Blue
	131-140	L328 - Follies Pink
	141-150	R3314 - Tough 1/4 Minusgreen
	151-160	L101 - Yellow
	161-170	L768 - Egg Yolk Yellow
	171-255	No function

Channel	Value	Function
CH14	000-010	No function
	011-030	2700K
	031-050	3000K
	051-070	3200K
	071-090	3500K
	091-110	4000K
	111-130	4200K
	131-150	4500K
	151-170	5600K
	171-190	6000K
	191-210	6500K
	211-230	7200K
	231-255	8000K
CH15	000-009	No function
	010-099	Strobe (slow-fast)
	100-109	No function
	110-179	Lightning strobe
	180-189	No function
	190-255	Random strobe
CH16	000-009	Dimming mode (set in menu)
	010-029	No function
	030-069	Dimming speed 1
	070-129	Dimming speed 2
	130-189	Dimming speed 3
	190-255	Dimming speed 4
CH17	000-009	No function
	010-080	Live performance mode
	081-160	Studio performance mode
	161-240	Power performance mode
	241-255	No function

11 channel mode (COLOUR 8BIT):

Channel	Value	Function
CH1	000-255	Master dimmer (0-100%)
CH2	000-255	Red (0-100%)
CH3	000-255	Green (0-100%)
CH4	000-255	Blue (0-100%)
CH5	000-255	Amber (0-100%)
CH6	000-255	Lime (0-100%)
CH7	000-010	No function
	011-020	L106 - Primary Red
	021-030	R05 - Rose Tint
	031-040	L194 - Surprise Pink
	041-050	R54 - Special Lavender
	051-060	L019 - Fire
	061-070	R08 - Pale Gold
	071-080	R89 - Moss Green
	081-090	R86 - Pea Green
	091-100	L213 - White Flame Green
	101-110	R377 - Iris Purple
	111-120	R80 - Primary Blue
	121-130	L202 - Half C.T. Blue
	131-140	L328 - Follies Pink
	141-150	R3314 - Tough 1/4 Minusgreen
	151-160	L101 - Yellow
	161-170	L768 - Egg Yolk Yellow
	171-255	No function
	000-010	No function
	011-030	2700K
	031-050	3000K
CH8	051-070	3200K
	071-090	3500K
	091-110	4000K
	111-130	4200K
	131-150	4500K
	151-170	5600K
	171-190	6000K
	191-210	6500K
	211-230	7200K
	231-255	8000K

Channel	Value	Function
CH9	000-009	No function
	010-099	Strobe (slow-fast)
	100-109	No function
	110-179	Lightning strobe
	180-189	No function
	190-255	Random strobe
CH10	000-009	Dimming mode (set in menu)
	010-029	No function
	030-069	Dimming speed 1
	070-129	Dimming speed 2
	130-189	Dimming speed 3
	190-255	Dimming speed 4
CH11	000-009	No function
	010-080	Live performance mode
	081-160	Studio performance mode
	161-240	Power performance mode
	241-255	No function

8 channel mode (HSIC):

Channel	Value	Function
CH1	000-255	Intensity (0-100%)
CH2	000-255	Hue
CH3	000-255	Hue fine
CH4	000-255	Saturation
CH5	000-010	No function
	011-030	2700K
	031-050	3000K
	051-070	3200K
	071-090	3500K
	091-110	4000K
	111-130	4200K
	131-150	4500K
	151-170	5600K
	171-190	6000K
	191-210	6500K
	211-230	7200K
	231-255	8000K
CH6	000-009	No function
	010-099	Strobe (slow-fast)
	100-109	No function
	110-179	Lightning strobe
	180-189	No function
	190-255	Random strobe
CH7	000-009	Dimming mode (set in menu)
	010-029	No function
	030-069	Dimming speed 1
	070-129	Dimming speed 2
	130-189	Dimming speed 3
	190-255	Dimming speed 4
CH8	000-009	No function
	010-080	Live performance mode
	081-160	Studio performance mode
	161-240	Power performance mode
	241-255	No function

8 channel mode (SIMPLE):

Channel	Value	Function
CH1	000-255	Master dimmer (0-100%)
CH2	000-255	Red (0-100%)
CH3	000-255	Green (0-100%)
CH4	000-255	Blue (0-100%)
CH5	000-255	Amber (0-100%)
CH6	000-255	Lime (0-100%)
CH7	000-009	No function
	010-099	Strobe (slow-fast)
	100-109	No function
	110-179	Lightning strobe
	180-189	No function
CH8	190-255	Random strobe
	000-009	No function
	010-080	Live performance mode
	081-160	Studio performance mode
	161-240	Power performance mode
	241-255	No function

6 channel mode (SDO):

Channel	Value	Function
CH1	000-255	Master dimmer (0-100%)
CH2	000-010	No function
	011-020	L106 - Primary Red
	021-030	R05 - Rose Tint
	031-040	L194 - Surprise Pink
	041-050	R54 - Special Lavender
	051-060	L019 - Fire
	061-070	R08 - Pale Gold
	071-080	R89 - Moss Green
	081-090	R86 - Pea Green
	091-100	L213 - White Flame Green
	101-110	R377 - Iris Purple
	111-120	R80 - Primary Blue
	121-130	L202 - Half C.T. Blue
	131-140	L328 - Follies Pink
	141-150	R3314 - Tough 1/4 Minusgreen
	151-160	L101 - Yellow
	161-170	L768 - Egg Yolk Yellow
	171-255	No function
CH3	000-010	No function
	011-030	2700K
	031-050	3000K
	051-070	3200K
	071-090	3500K
	091-110	4000K
	111-130	4200K
	131-150	4500K
	151-170	5600K
	171-190	6000K
CH4	191-210	6500K
	211-230	7200K
	231-255	8000K
	000-009	No function
	010-099	Strobe (slow-fast)
	100-109	No function
CH5	110-179	Lightning strobe
	180-189	No function
	190-255	Random strobe

Channel	Value	Function
CH5	000-009	Dimming mode (set in menu)
	010-029	No function
	030-069	Dimming speed 1
	070-129	Dimming speed 2
	130-189	Dimming speed 3
CH6	190-255	Dimming speed 4
	000-009	No function
	010-080	Live performance mode
	081-160	Studio performance mode
	161-240	Power performance mode
	241-255	No function