

Sparkly Wash 19

3 Modes 14 - 25 -90

14 CHs

Channel	Function	Value	Description
1	Strobe	0 --> 19	Strobe Off
		20 --> 24	Strobe On
		25 --> 64	Fast to Slow Strobe
		65 --> 69	Strobe On
		70 --> 84	Fast to Slow Open Pulse
		85 --> 89	Strobe On
		90 --> 104	Fast to Slow Close Pulse
		105 --> 109	Strobe On
		110 --> 124	Fast to Slow Random Strobe
		125 --> 129	Strobe On
		130 --> 144	Fast to Slow Random Open
		145 --> 149	Strobe On
		150 --> 164	Fast to Slow Random Close
		165 --> 169	Strobe On
		170 --> 184	Fast to Slow Pulse
		185 --> 189	Strobe On
		190 --> 204	Fast to Slow Random Pulse
		205 --> 209	Strobe On
		210 --> 224	Fast to Slow Strobe
		225 --> 229	Strobe On
230 --> 244	Fast to Slow Exposure		
245 --> 255	Strobe On		
2	Dimmer	0 --> 255	0% to 100% Dimmer
3	Zoom	0 --> 255	0% to 100% Zoom
4	Pan	0 --> 255	540° Pan
5	Pan Fine	0 --> 255	Pan Fine
6	Tilt	0 --> 255	270° Tilt
7	Tilt Fine	0 --> 255	Tilt Fine
8	Control	0	Safe
		10 --> 14	Reset ALL
		15 -> 39	Safe
		40 --> 44	P/T Normal
		45 --> 49	P/T Fast
		50 --> 54	P/T Slow
		55 --> 255	Fan Fast

9	Color Macro	0 --> 9	Open
		10 --> 14	Red
		15 --> 19	Green
		20 --> 24	Blue
		25 --> 29	White
		30 --> 34	2300
		35 --> 39	2500
		40 --> 44	2700
		45 --> 49	3000
		50 --> 54	3200
		55 --> 59	3300
		60 --> 64	3700
		65 --> 69	4300
		70 --> 74	4500
		75 --> 79	4600
		80 --> 84	5000
		85 --> 89	5500
		90 --> 94	5600
		95 --> 99	6500
		100 --> 104	Light Yellow
		105 --> 109	Apple Green
		110 --> 114	Pink
		115 --> 119	Orange
		120 --> 124	Deep Orange
		125 --> 129	UV
130 --> 134	Open		
135 --> 174	Fast to Slow CW Scroll		
175 --> 179	Stop		
180 --> 219	Slow to Fast CCW Scroll		
220 --> 224	Open		
225 --> 255	Fast to Slow Random Colors		
10	Red	0 --> 255	0% to 100% Red LEDs
11	Green	0 --> 255	0% to 100% Green LEDs
12	Blue	0 --> 255	0% to 100% Blue LEDs
13	White	0 --> 255	0% to 100% White LEDs
14	Color Change	0 --> 7	Open
		8 --> 39	Red to Yellow
		40 --> 71	Yellow to Green
		72 --> 103	Green to Cyan
		104 --> 135	Cyan to Blue
		136 --> 167	Blue to Magenta
		168 --> 199	Magenta to Red
		200 --> 231	Red to White
		232 --> 255	Scroll
		0 --> 255	Index

25 CHls

Channel	Function	Value	Description
1	Strobe	0 --> 19	Strobe Off
		20 --> 24	Strobe On
		25 --> 64	Fast to Slow Strobe
		65 --> 69	Strobe On
		70 --> 84	Fast to Slow Open Pulse
		85 --> 89	Strobe On
		90 --> 104	Fast to Slow Close Pulse
		105 --> 109	Strobe On
		110 --> 124	Fast to Slow Random Strobe
		125 --> 129	Strobe On
		130 --> 144	Fast to Slow Random Open
		145 --> 149	Strobe On
		150 --> 164	Fast to Slow Random Close
		165 --> 169	Strobe On
		170 --> 184	Fast to Slow Pulse
		185 --> 189	Strobe On
		190 --> 204	Fast to Slow Random Pulse
		205 --> 209	Strobe On
		210 --> 224	Fast to Slow Strobe
		225 --> 229	Strobe On
230 --> 244	Fast to Slow Exposure		
244 --> 255	Strobe On		
2	Dimmer	0 --> 255	0% to 100% Dimmer
3	Zoom	0 --> 255	0% to 100% Zoom
4	Pan	0 --> 255	540° Pan
5	Pan Fine	0 --> 255	Pan Fine
6	Tilt	0 --> 255	270° Tilt
7	Tilt Fine	0 --> 255	Tilt Fine
8	Control	0	Safe
		10 --> 14	Reset ALL
		15 --> 39	Safe
		40 --> 44	P/T Normal
		45 --> 49	P/T Fast
		50 --> 54	P/T Slow
		55 --> 255	Fan Fast

9	Color Macro	0 --> 9	Open
		10 --> 14	Red
		15 --> 19	Green
		20 --> 24	Blue
		25 --> 29	White
		30 --> 34	2300
		35 --> 39	2500
		40 --> 44	2700
		45 --> 49	3000
		50 --> 54	3200
		55 --> 59	3300
		60 --> 64	3700
		65 --> 69	4300
		70 --> 74	4500
		75 --> 79	4600
		80 --> 84	5000
		85 --> 89	5500
		90 --> 94	5600
		95 --> 99	6500
		100 --> 104	Light Yellow
		105 --> 109	Apple Green
		110 --> 114	Pink
		115 --> 119	Orange
		120 --> 124	Deep Orange
		125 --> 129	UV
130 --> 134	Open		
135 --> 174	Fast to Slow CW Scroll		
175 --> 179	Stop		
180 --> 219	Slow to Fast CCW Scroll		
220 --> 224	Open		
225 --> 255	Fast to Slow Random Colors		
10	Red	0 --> 255	0% to 100% Red LEDs
11	Green	0 --> 255	0% to 100% Green LEDs
12	Blue	0 --> 255	0% to 100% Blue LEDs
13	White	0 --> 255	0% to 100% White LEDs
14	Color Change	0 --> 7	Open
		8 --> 39	Red to Yellow
		40 --> 71	Yellow to Green
		72 --> 103	Green to Cyan
		104 --> 135	Cyan to Blue
		136 --> 167	Blue to Magenta
		168 --> 199	Magenta to Red
		200 --> 231	Red to White
		232 --> 255	Scroll
0 --> 255	Index		

15	LED Gobo	0 --> 4	Open
		5 --> 9	Gobo 1
		10 --> 14	Gobo 2
		15 --> 19	Gobo 3
		20 --> 24	Gobo 4
		25 --> 29	Gobo 5
		30 --> 34	Gobo 6
		35 --> 39	Gobo 7
		40 --> 44	Gobo 8
		45 --> 49	Gobo 9
		50 --> 54	Gobo 10
		55 --> 59	Gobo 11
		60 --> 64	Gobo 12
		65 --> 69	Gobo 13
		70 --> 74	Gobo 14
		75 --> 79	Gobo 15
		80 --> 84	Gobo 16
		85 --> 89	Gobo 17
		90 --> 94	Gobo 18
		95 --> 99	Gobo 19
		100 --> 104	Gobo 20
		105 --> 109	Gobo 21
		110 --> 114	Gobo 22
		115 --> 119	Gobo 23
		120 --> 124	Gobo 24
		125 --> 129	Gobo 25
		130 --> 134	Gobo 26
		135 --> 139	Gobo 27
		140 --> 144	Gobo 28
		145 --> 149	Gobo 29
		150 --> 154	Gobo 30
		155 --> 159	Gobo 31
		160 --> 164	Gobo 32
		165 --> 169	Gobo 33
		170 --> 174	Gobo 34
		175 --> 179	Gobo 35
		180 --> 184	Gobo 36
		185 --> 189	Gobo 37
		190 --> 194	Gobo 38
		195 --> 199	Gobo 39
200 --> 204	Gobo 40		
205 --> 224	Gobo Change Slower		
225 --> 234	Stop		
235 --> 255	Gobo Change Faster		

16	Effect	0 --> 4	No Effect
		5 --> 14	Effect 1
		15 --> 24	Effect 2
		25 --> 34	Effect 3
		35 --> 44	Effect 4
		45 --> 54	Effect 5
		55 --> 64	Effect 6
		65 --> 74	Effect 7
		75 --> 84	Effect 8
		85 --> 94	Effect 9
		95 --> 104	Effect 10
		105 --> 114	Effect 11
		115 --> 124	Effect 12
		125 --> 134	Effect 13
		135 --> 144	Effect 14
		145 --> 154	Effect 15
		155 --> 164	Effect 16
		165 --> 174	Effect 17
		175 --> 184	Effect 18
185 --> 194	Effect 19		
		195 --> 255	1 min Auto Change
17	Effect Speed	0 --> 255	0% to 100% Effect Speed
18	Effect Fade	0 --> 255	0% to 100% Effect Fade
19	Effect Red	0 --> 255	0% to 100% Red LEDs
20	Effect Green	0 --> 255	0% to 100% Green LEDs
21	Effect Blue	0 --> 255	0% to 100% Blue LEDs
22	Effect White	0 --> 255	0% to 100% White LEDs
23	Effect Dimmer	0 --> 255	0% to 100% Effect Dimmer
24	Effect Backlight	0 --> 255	0% to 100% Backlight Dimmer
25	Reserved	0 --> 255	Reserved

90 CHs

Channel	Function	Value	Description
1	Strobe	0 --> 19	Strobe Off
		20 --> 24	Strobe On
		25 --> 64	Fast to Slow Strobe
		65 --> 69	Strobe On
		70 --> 84	Fast to Slow Open Pulse
		85 --> 89	Strobe On
		90 --> 104	Fast to Slow Close Pulse
		105 --> 109	Strobe On
		110 --> 124	Fast to Slow Random Strobe
		125 --> 129	Strobe On
		130 --> 144	Fast to Slow Random Open
		145 --> 149	Strobe On
		150 --> 164	Fast to Slow Random Close
		165 --> 169	Strobe On
		170 --> 184	Fast to Slow Pulse
		185 --> 189	Strobe On
		190 --> 204	Fast to Slow Random Pulse
		205 --> 209	Strobe On
		210 --> 224	Fast to Slow Strobe
		225 --> 229	Strobe On
230 --> 244	Fast to Slow Exposure		
244 --> 255	Strobe On		
2	Dimmer	0 --> 255	0% to 100% Dimmer
3	Zoom	0 --> 255	0% to 100% Zoom
4	Pan	0 --> 255	540° Pan
5	Pan Fine	0 --> 255	Pan Fine
6	Tilt	0 --> 255	270° Tilt
7	Tilt Fine	0 --> 255	Tilt Fine
8	Control	0	Safe
		10 --> 14	Reset ALL
		15 --> 39	Safe
		40 --> 44	P/T Normal
		45 --> 49	P/T Fast
		50 --> 54	P/T Slow
		55 --> 255	Fan Fast

9	Color Macro	0 --> 9	Open
		10 --> 14	Red
		15 --> 19	Green
		20 --> 24	Blue
		25 --> 29	White
		30 --> 34	2300
		35 --> 39	2500
		40 --> 44	2700
		45 --> 49	3000
		50 --> 54	3200
		55 --> 59	3300
		60 --> 64	3700
		65 --> 69	4300
		70 --> 74	4500
		75 --> 79	4600
		80 --> 84	5000
		85 --> 89	5500
		90 --> 94	5600
		95 --> 99	6500
		100 --> 104	Light Yellow
		105 --> 109	Apple Green
		110 --> 114	Pink
		115 --> 119	Orange
		120 --> 124	Deep Orange
		125 --> 129	UV
130 --> 134	Open		
135 --> 174	Fast to Slow CW Scroll		
175 --> 179	Stop		
180 --> 219	Slow to Fast CCW Scroll		
220 --> 224	Open		
225 --> 255	Fast to Slow Random Colors		
10	Red	0 --> 255	0% to 100% Red LEDs
11	Green	0 --> 255	0% to 100% Green LEDs
12	Blue	0 --> 255	0% to 100% Blue LEDs
13	White	0 --> 255	0% to 100% White LEDs
14	Color Change	0 --> 7	Open
		8 --> 39	Red to Yellow
		40 --> 71	Yellow to Green
		72 --> 103	Green to Cyan
		104 --> 135	Cyan to Blue
		136 --> 167	Blue to Magenta
		168 --> 199	Magenta to Red
		200 --> 231	Red to White
		232 --> 255	Scroll
0 --> 255	Index		

15	P 1 Red	0 --> 255	0% to 100% Red LEDs
16	P 1 Green	0 --> 255	0% to 100% Green LEDs
17	P 1 Blue	0 --> 255	0% to 100% Blue LEDs
18	P 1 White	0 --> 255	0% to 100% White LEDs
19	P 2 Red	0 --> 255	0% to 100% Red LEDs
20	P 2 Green	0 --> 255	0% to 100% Green LEDs
21	P 2 Blue	0 --> 255	0% to 100% Blue LEDs
22	P 2 White	0 --> 255	0% to 100% White LEDs
23	P 3 Red	0 --> 255	0% to 100% Red LEDs
24	P 3 Green	0 --> 255	0% to 100% Green LEDs
25	P 3 Blue	0 --> 255	0% to 100% Blue LEDs
26	P 3 White	0 --> 255	0% to 100% White LEDs
27	P 4 Red	0 --> 255	0% to 100% Red LEDs
28	P 4 Green	0 --> 255	0% to 100% Green LEDs
29	P 4 Blue	0 --> 255	0% to 100% Blue LEDs
30	P 4 White	0 --> 255	0% to 100% White LEDs
31	P 5 Red	0 --> 255	0% to 100% Red LEDs
32	P 5 Green	0 --> 255	0% to 100% Green LEDs
33	P 5 Blue	0 --> 255	0% to 100% Blue LEDs
34	P 5 White	0 --> 255	0% to 100% White LEDs
35	P 6 Red	0 --> 255	0% to 100% Red LEDs
36	P 6 Green	0 --> 255	0% to 100% Green LEDs
37	P 6 Blue	0 --> 255	0% to 100% Blue LEDs
38	P 6 White	0 --> 255	0% to 100% White LEDs
39	P 7 Red	0 --> 255	0% to 100% Red LEDs
40	P 7 Green	0 --> 255	0% to 100% Green LEDs
41	P 7 Blue	0 --> 255	0% to 100% Blue LEDs
42	P 7 White	0 --> 255	0% to 100% White LEDs
43	P 8 Red	0 --> 255	0% to 100% Red LEDs
44	P 8 Green	0 --> 255	0% to 100% Green LEDs
45	P 8 Blue	0 --> 255	0% to 100% Blue LEDs
46	P 8 White	0 --> 255	0% to 100% White LEDs
47	P 9 Red	0 --> 255	0% to 100% Red LEDs
48	P 9 Green	0 --> 255	0% to 100% Green LEDs
49	P 9 Blue	0 --> 255	0% to 100% Blue LEDs
50	P 9 White	0 --> 255	0% to 100% White LEDs
51	P 10 Red	0 --> 255	0% to 100% Red LEDs
52	P 10 Green	0 --> 255	0% to 100% Green LEDs
53	P 10 Blue	0 --> 255	0% to 100% Blue LEDs
54	P 10 White	0 --> 255	0% to 100% White LEDs

55	P 11 Red	0 --> 255	0% to 100% Red LEDs
56	P 11 Green	0 --> 255	0% to 100% Green LEDs
57	P 11 Blue	0 --> 255	0% to 100% Blue LEDs
58	P 11 White	0 --> 255	0% to 100% White LEDs
59	P 12 Red	0 --> 255	0% to 100% Red LEDs
60	P 12 Green	0 --> 255	0% to 100% Green LEDs
61	P 12 Blue	0 --> 255	0% to 100% Blue LEDs
62	P 12 White	0 --> 255	0% to 100% White LEDs
63	P 13 Red	0 --> 255	0% to 100% Red LEDs
64	P 13 Green	0 --> 255	0% to 100% Green LEDs
65	P 13 Blue	0 --> 255	0% to 100% Blue LEDs
66	P 13 White	0 --> 255	0% to 100% White LEDs
67	P 14 Red	0 --> 255	0% to 100% Red LEDs
68	P 14 Green	0 --> 255	0% to 100% Green LEDs
69	P 14 Blue	0 --> 255	0% to 100% Blue LEDs
70	P 14 White	0 --> 255	0% to 100% White LEDs
71	P 15 Red	0 --> 255	0% to 100% Red LEDs
72	P 15 Green	0 --> 255	0% to 100% Green LEDs
73	P 15 Blue	0 --> 255	0% to 100% Blue LEDs
74	P 15 White	0 --> 255	0% to 100% White LEDs
75	P 16 Red	0 --> 255	0% to 100% Red LEDs
76	P 16 Green	0 --> 255	0% to 100% Green LEDs
77	P 16 Blue	0 --> 255	0% to 100% Blue LEDs
78	P 16 White	0 --> 255	0% to 100% White LEDs
79	P 17 Red	0 --> 255	0% to 100% Red LEDs
80	P 17 Green	0 --> 255	0% to 100% Green LEDs
81	P 17 Blue	0 --> 255	0% to 100% Blue LEDs
82	P 17 White	0 --> 255	0% to 100% White LEDs
83	P 18 Red	0 --> 255	0% to 100% Red LEDs
84	P 18 Green	0 --> 255	0% to 100% Green LEDs
85	P 18 Blue	0 --> 255	0% to 100% Blue LEDs
86	P 18 White	0 --> 255	0% to 100% White LEDs
87	P 19 Red	0 --> 255	0% to 100% Red LEDs
88	P 19 Green	0 --> 255	0% to 100% Green LEDs
89	P 19 Blue	0 --> 255	0% to 100% Blue LEDs
90	P 19 White	0 --> 255	0% to 100% White LEDs