

# ETC<sup>®</sup> Eos Family Console Shortcut Keys



## Eos Family Software: Version 1.9.8

Keyboard [Scroll Lock] must be OFF

| Console Key            | PC                  |
|------------------------|---------------------|
| Shortcut List for Help | ;                   |
|                        | ?                   |
| 0                      | 0                   |
| 1                      | 1                   |
| 2                      | 2                   |
| 3                      | 3                   |
| 4                      | 4                   |
| 5                      | 5                   |
| 6                      | 6                   |
| 7                      | 7                   |
| 8                      | 8                   |
| 9                      | 9                   |
| . (decimal)            | . (decimal)         |
| - (minus)              | - (minus)           |
| + (plus)               | =                   |
|                        | +                   |
| +%                     | Shift Page Up       |
| +% (Mac)               | Shift Fn Up Arrow   |
| -%                     | Shift Page Down     |
| -% (Mac)               | Shift Fn Down Arrow |
| /                      | /                   |
| About                  | Control /           |
| Address/Dimmer         | Alt A               |
| Assert                 | Shift A             |
| Assert (Playback)      | Shift S             |
| At                     | A                   |
|                        | @                   |
|                        | *                   |
| Beam Filter            | Control B           |
| Beam Palette           | Alt B               |
| Blind                  | F3                  |
| Block                  | Shift B             |
| Capture                | Control P           |
| Channel Filter         | Shift C             |
| CIA Hide               | F5                  |
| Clear                  | Backspace           |
| Color Filter           | Control C           |
| Color Palette          | Alt C               |
| Copy To                | Shift P             |
| Cue                    | Q                   |
| Cue Only/Track         | X                   |
| Data                   | Shift D             |
| Delay                  | D                   |
| Delete                 | Delete              |
| Delete (Mac)           | Fn Delete           |
| Displays               | F9                  |
| Effect                 | Alt E               |

|                       |                   |
|-----------------------|-------------------|
| Encoder Display (Gio) | Alt F5            |
| Encoder Page Focus    | Control 5         |
| Encoder Page Color    | Control 6         |
| Encoder Page Image    | Control 7         |
| Encoder Page Form     | Control 8         |
| Encoder Page Shutter  | Control 9         |
| Encoder Page Custom   | Control 0 (zero)  |
| Enter                 | Enter             |
| Escape                | Escape            |
| Expand                | F11               |
| Fader Independent     | Shift I           |
| Fader Pages           | ] (right bracket) |
| Fan                   | Shift . (decimal) |
| Filter Mode (CIA)     | ` (apostrophe)    |
| Flexi-Channel         | F8                |
| Focus Filter          | Control F         |
| Focus Palette         | Alt F             |
| Format                | F4                |
| Frame                 | Shift F           |
| Freeze                | Shift Z           |
| Full                  | F                 |
| Go                    | Spacebar          |
|                       | Control G         |
| Go To Cue             | Shift G           |
| Go To Cue Zero        | Alt Z             |
| Group                 | G                 |
| Help                  | F1                |
| High / Low            | \                 |
| Home                  | Home              |
| Home (Mac)            | Fn Left Arrow     |
| Intensity Filter      | Control I         |
| Intensity Palette     | Alt I             |
| Label                 | B                 |
| Last                  | Page Down         |
| Last (Mac)            | Fn Down Arrow     |
| Learn                 | L                 |
| Level                 | V                 |
| Live                  | F2                |
| Load                  | Control F2        |
|                       | Control 2         |
| Macro                 | Shift F8          |
|                       | Control 4         |
| Manual Override       | Shift M           |
| Mark                  | M                 |
| Mirror, Start         | Alt M             |
| Mirror, Stop          | Alt X             |
| ML Controls           | Alt F5            |
|                       |                   |

# E T C Eos Family

## Console Shortcut Keys



|                    |                    |
|--------------------|--------------------|
| More Softkeys      | Shift F7           |
|                    | Alt 7              |
| Next               | Page Up            |
| <i>Next (Mac)</i>  | <i>Fn Up Arrow</i> |
| Off                | Shift O            |
| Offset             | Control O          |
| Out                | O                  |
| Page Left          | Left Arrow         |
| Page Right         | Right Arrow        |
| Page Up            | Up Arrow           |
| Page Down          | Down Arrow         |
| Parameters (CIA)   | E                  |
| Park               | K                  |
| Park Display       | Alt K              |
| Part               | P                  |
| Patch              | Alt F2             |
| Pixelmap           | Alt P              |
| Preset             | Alt S              |
| Query              | Y                  |
| Rate               | Shift R            |
| Recall From        | Shift L            |
| Record             | R                  |
| <b>Record Only</b> | <b>W</b>           |
| Release            | Shift U            |
| Rem Dim            | H                  |
| Scroll Lock        | Alt L              |
| Select             | F6                 |
| Select Active      | Control V          |
| Select Last        | Control L          |
| Select Manual      | Control M          |
| Setup              | Alt F3             |
| <b>Shift</b>       | <b>Z</b>           |
| Snapshot           | Control 1          |
|                    | F9                 |
| Sneak              | N                  |
| Softkey 1          | Shift F1           |
|                    | Alt 1              |
| Softkey 2          | Shift F2           |
|                    | Alt 2              |
| Softkey 3          | Shift F3           |
|                    | Alt 3              |
| Softkey 4          | Shift F4           |
|                    | Alt 4              |
| Softkey 5          | Shift F5           |
|                    | Alt 5              |
| Softkey 6          | Shift F6           |
|                    | Alt 6              |
| Stop/Back          | Control F3         |
|                    | Control 3          |
| Stop Effect        | Shift E            |
| Submaster          | S                  |
| Tab                | Tab                |

|                 |           |
|-----------------|-----------|
| Time            | I         |
| Timing Disable  | Shift T   |
| Time (Displays) | Control T |
| Thru            | T         |
| Trace           | J         |
| Undo            | C         |
| Update          | U         |

# ETC Eos Family Console Shortcut Keys



1

## Shell Shortcut Keys

| Shell Key   | PC          |
|-------------|-------------|
| 0           | 0           |
| 1           | 1           |
| 2           | 2           |
| 3           | 3           |
| 4           | 4           |
| 5           | 5           |
| 6           | 6           |
| 7           | 7           |
| 8           | 8           |
| 9           | 9           |
| . (decimal) | . (decimal) |
| - (minus)   | - (minus)   |

|              |              |
|--------------|--------------|
| + (plus)     | =            |
| /            | /            |
| Arrow, Down  | Arrow, Down  |
| Arrow, Left  | Arrow, Left  |
| Arrow, Right | Arrow, Right |
| Arrow, Up    | Arrow, Up    |
| Back         | Esc          |
| Clear        | Backspace    |
| Delete       | Delete       |
| Enter        | Enter        |
| Escape       | Esc          |
| Select       | Return       |
| Swap         | Tab          |