DMX2

Wiring and Software Guide

DMX2 Wiring Overview

Position #4 DMX Termination

Power Indicator

DMX Status

36V IN

Hardwire DMX Connections

DMX IN Com

DMX IN -

DMX IN +

DMX TH Com

DMX TH -

DMX TH +

LED1

LED2

UP

MENU

LEFT

RIGHT

ENTER

DOWN

W

B

G

R

Output to LED

RJ45 DMX Connection
(Standard RJ45 Termination)

RF MMCX Connection for Wireless

Control Buttons

# DMX2 Software Overview

Press enter to Access the Manual Control screen.

Adjust the intensity of white only by using the up and down control buttons.

When finished press the menu control button to return to the main menu.

Use the up and down control buttons and enter to select the Settings menu.

Use the up and down control buttons and enter to select the DMX Address menu.

Use the up and down control buttons to select the DMX address.

When finished press the menu control button to return to the Settings menu.

Use the up and down control buttons and enter to select the DMX Mode menu.

Use the up and down control buttons to select the DMX mode.

Use the up and down control buttons and enter to select the DMX Failure Mode menu.

Use the up and down control buttons to select which failure mode you desire.
1. Turn on – white only when DMX is lost.
2. Use last DMX Value when DMX is lost.
3. Turn off when DMX is lost.

When finished press the menu control button to return to the settings menu.

Use the up and down control buttons and enter to select the Thermal Mass menu.

Use the up and down control buttons to select which Thermal Mass you desire.
1. Majestic replicates the dimming response of a 2000w halogen bulb.
2. Incandescent replicates the dimming response of a 500w halogen bulb.
3. Hyper replicate the dimming response of a 25w halogen bulb.

When finished press the menu control button to return to the settings menu.

Main Menu


```
Menu
1. Manual Control
2. Settings
3.▶Information
```

Use the up and down control buttons and enter to select the Information menu.

Information Menu


```
Driver 30C (336?)
LED 25C (409?)
Ver 0.5.001
SN: 4769
```

Driver Temperature

LED Temperature

Software Version

Software Serial #

When finished press the menu control button to return to the main menu.

Main Menu


```
Menu
2. Settings
3. Information
4.▶CRMX Radio Link
```

Use the up and down control buttons and enter to select the CRMX Radio Link menu.

CRMX Radio Link Menu


```
CRMX Radio Link
Unlinked
```

If you purchased the Lumen Radio Wireless option this is where it can be linked and unlinked.