

Layer Light (3.1)

Layer Light 3.1				20 channels	
Function	DMX	DMX (16bit)	Default	Range	Notes
Level	1		0	0-255	
Mixermode	2		120	0	Additive Dissolve
				10	Subtractive Dissolve
				20	Darken
				30	Lighten
				40	Softlight
				50	Softlight Inverse
				60	Hardlight
				70	Overlay
				80	Difference
				90	Multiply
				100	Screen
				110	Opaque
				120	Sprite
				130	Luminance Key
				140	Matte
Live Mask	3		0	0 - 255	
Source Type	4		0	0	Media PLayer
				15	Live Input
				25	Generator
				35	Relays
				45	Screen Thief
				55	Text Engine
Bank	5		0	0 - 255	
Clip	6		0	0 - 255	
Playmode	7		15	0	Forward
				15	Forward Loop
				25	Backward
				35	Backward Loop
				45	Ping Pong
				55	Random
				65	In
				75	Out
				85	Reserved
Speed	8		64	0-255	
In Point	9	10	0	0-65535	Sets In-point
Out Point	11	12	65535	0-65535	Sets Out-Point

Live Input Select	13		0	0	Disabled
				10	Input 1
				20	Input 2
				30	Input 3
				40	Input 4
				50	Input 5
				60	Input 6
				70	Input 7
				80	Input 8
Generator Select	14		0	0-255	See separate list
Generator Level	15		0	0-255	
Generator Param 1	16		128	0-255	
Generator Param 2	17		128	0-255	
Generator Param 3	18		128	0-255	
Audio Volume	19		0	0 - 255	
Audio Pan	20		128	0 - 255	