

Master Pan Mode (3.2)

3.2 Master Pan Mode				91 Channels		
Output	Function	DMX	DMX (16bit)	Default	Range	Notes
	Level	1		255	0-255	
	Keystone X1	2	3	0	0-65535	
	Keystone Y1	4	5	0	0-65535	
	Keystone X2	6	7	65535	0-65535	
	Keystone Y2	8	9	0	0-65535	
	Keystone X3	10	11	65535	0-65535	
	Keystone Y3	12	13	65535	0-65535	
	Keystone X4	14	15	0	0-65535	
	Keystone Y4	16	17	65535	0-65535	
	Red	18		128	0-127	Subtract Colour
					128	Normal
					129-255	Add Colour
	Green	19		128	0-127	Subtract Colour
					128	Normal
					129-255	Add Colour
	Blue	20		128	0-127	Subtract Colour
					128	Normal
					129-255	Add Colour
	Brightness	21		128	0-255	
	Contrast	22		128	0-255	
	Invert	23		0	0-127	Invert Off
					128- 255	Invert On
	Rotation	24	25	16384	0 - 32768	Index Position
					32769 - 49151	Continuous rotation CW
					49152	Stop
					49153 - 65535	Continuous rotation CCW
	Pos X	26	27	32768	0-65535	
	Pos Y	28	29	32768	0-65535	
	Zoom	30	31	32768	0-65535	
	FX1Sel	32		0	0-255	
	FX1Level	33		0	0-255	
	FX1Par1	34		0	0-255	
	FX1Par2	35		0	0-255	
	FX1Par3	36		0	0-255	
	FX1Par4	37		0	0-255	

	FX1Par5	38		0	0-255	
	FX2Sel	39		0	0-255	
	FX2Level	40		0	0-255	
	FX2Par1	41		0	0-255	
	FX2Par2	42		0	0-255	
	FX2Par3	43		0	0-255	
	FX2Par4	44		0	0-255	
	FX2Par5	45		0	0-255	
	WarpA Select	46		0	0-255	Selected warp for Channel A
	WarpB Select	47		0	0-255	Selected warp for Channel B
	Warp Mix	48		0	0	Warp Channel B
					255	Warp Channel A
	Live Mask	49		0	0-255	
2	Keystone X1	50	51	0	0-65535	
	Keystone Y1	52	53	0	0-65535	
	Keystone X2	54	55	65535	0-65535	
	Keystone Y2	56	57	0	0-65535	
	Keystone X3	58	59	65535	0-65535	
	Keystone Y3	60	61	65535	0-65535	
	Keystone X4	62	63	0	0-65535	
	Keystone Y4	64	65	65535	0-65535	
	Red	66		128	0-127	Subtract Colour
					128	Normal
					129-255	Add Colour
	Green	67		128	0-127	Subtract Colour
					128	Normal
					129-255	Add Colour
	Blue	68		128	0-127	Subtract Colour
					128	Normal
					129-255	Add Colour
	Brightness	69		128	0-255	
	Contrast	70		128	0-255	
	Invert	71		0	0-127	Invert Off
					128-255	Invert On
	Rotation	72	73	16384	0 - 32768	Index Position
					32769 - 49151	Continuous rotation CW
					49152	Stop
					49153 - 65535	Continuous rotation CCW
	Pos X	74	75	32768	0-65535	
	Pos Y	76	77	32768	0-65535	

	Zoom	78	79	32768	0-65535	
	Warp2 A Select	80		0	0-255	Selected warp for Channel A
	Warp2 B Select	81		0	0-255	Selected warp for Channel B
	Warp 2 Mix	82		0	0	Warp Channel B
					255	Warp Channel A
	Video Map Enable	83		0	0-128	Disabled
					128-255	Enabled
	Video Map Mixmode	84		0	0-255	
	Mix Morph	85		0	0-128	Morph Off
					128-255	Morph On
	Map select A	86		0	0-255	
	Map Select B	87		0	0-255	
	Audio Volume	88		0	0-255	
	Region Mapper	89		0	0-127	Disable
					128-255	Enable
	Timecode Shift	90	91	32768	0-65535	Timecode